

# GL1800 PTT Bracket Installation Instructions



1. Align bracket flush with bottom vents as shown.
2. Hold in place while fastening with #10 screw.
3. Route cable down handle bar.
4. Connect to FRset/CBSet (or extender cable, if required for your installation)

Kennedy Technology Group, Inc.  
614 Ridgeway, Rose Hill, Kansas 67133 - USA  
voice 316.776.1111 • fax 316.776.9035 • email:kennedy@cellset.com

65147R0