

User's Guide

CellSet MC/SP4

Kennedy Technology Group, Inc.

email:kennedy@cellset.com

www.cellset.com

Document part number: 65218R2

Thank you for purchasing our product!

We hope that your new *CellSet* gives you many hours of clear and comfortable operation.

This product was designed to connect to a variety of intercoms and cell phones. It must be used in conjunction with a KTG Intercom Harness; a KTG Power Harness; and a KTG Cell Phone Harness (each sold and packaged separately).

Connect *CellSet* jack **J1** to the Intercom Harness you purchased.

Next connect *CellSet's* plug **P1** to the Cell Phone Harness you purchased.

Then connect *CellSet* plug **P2** to the Power Harness you purchased.

Refer to the instructions sheets provided with those harnesses. When you complete those installations refer back to this sheet.

Mount the box to the bike using tie wraps.

Turn on your intercom and adjust the intercom volume to its usual settings. Put on your helmet/helmet.

To talk on the phone after you take or make a call, simply speak into your headset's microphone.

Many phones can be programmed for auto-answer and auto-disconnect. If you plan on only receiving phone calls, you might consider mounting the phone in the trunk.

IMPORTANT NOTES

CellSet is based on speakerphone technology. As such,, it is sensitive to wind noise. Furthermore, it automatically attenuates background (i.e. road) noise. To be properly heard by the receiving party, you must speak at least twice as loud as any background noise picked up by your headset microphone.

If your phone does not ring through its headset jack, then you must program your phone for "auto answer" in order to receive calls.

If you hear a buzzing noise when you place or receive a call, try to locate the cell phone farther from *CellSet*. The buzzing may be worse when the bike is inside a building. If available, connect an aftermarket or OEM remote mount antenna.

Try to mount the phone in an upright position.

Route the cable to the cell phone so that there is no excess line close to the phone.

Attach a remote antenna (if available for your cell phone make and model)

CellSet is internally fused with a solid state, auto-resetting, 1/4 Amp fuse. To reset the fuse, turn the bike's power "off", wait a few seconds then turn it back "on".