

CellSet User's Guide

(Part Number 65090R1R1)

Model LRC


Kennedy Technology Group, Inc.
614 Ridgeway, Rose Hill, Kansas 67133 USA
voice 316.776.1111 - fax 316.776.9035
email: kennedy@cellset.com

Thank you for purchasing our product!

We hope that your new *CellSet* gives you many hours of clear and comfortable cellular telephone operation.

Using *CellSet* is *EASY!* Install the battery we provided and plug *CellSet* between your headset and intercom. Then plug *CellSet's* 2.5mm plug into the headset jack on your cellular telephone.

The plugs below correspond to the *CellSet* option you purchased.



The Standard plug is employed by most cellular telephones, and there are a wide array of adapters available that allow this plug to connect to phones with proprietary or differently wired headset jacks via an adapter.

The NOK4 plug is employed by those Nokia phones which list headset #HDC-5 as an accessory. There are no adapters available that allow this plug to connect to other phones.

The SR22 plug is employed by Samsung phones which have 2.5 mm headset jacks with a metal outer ring. There are no adapters available that allow this plug to connect to other phones.

To talk on the phone after you answer or make a call, make sure the red button on the side of the *CellSet* is in the "In-line" (pressed in) position. Then simply the speak into your headset's microphone and listen on your headphones.

CellSet doesn't have a battery: It draws its power from the panel. So in the event of a panel power failure, the *CellSet* is inoperative.